


cab

**Tamp Applicator with
Swing and Lift Cylinder
Type 3200 / Type 3200H
Part-No. 5535922 / 5537964**

Operating Instructions

Edition 11/03





cab-Produkttechnik

Gesellschaft für

Computer- und Automations-
bausteine mbH & Co KG

Postfach 19 04 D-76007 Karlsruhe

Wilhelm-Schickard-Straße 14 D-76131 Karlsruhe

Telefon 0721 / 66 26-0

Telexfax 0721 / 66 26-249

copyright by cab / 9008157 / N45 / 10

Angaben zu Lieferumfang, Aussehen, Leistung, Maßen und Gewicht entsprechen unseren Kenntnissen zum Zeitpunkt der Drucklegung. Änderungen sind vorbehalten.

All specifications about delivery, design, performance and weight are given to the best of our current knowledge and are subject to change without prior notice.

Table of Contents

Copyright	2
Table of Contents	3
1. Product Description	4
Function	4
Positions of the Pad	5
Technical Data	5
2. Equipment Supplied	6
3. Safety Instructions	7
4. Installation	8
Installing the Tamp Applicator on the Apollo	8
Installing the Tamp Applicator on the Hermes	9
Installing the Service Unit	10
Connections	11
5. Adjustments	12
5.1. Mechanical Adjustments	12
Angle of the PAd in the Starting Position	12
Adjusting the Level and the Side of the Cylinder Unit on the Apollo	14
Adjusting the Level and the Side of the Cylinder Unit on the Hermes	15
Tuning the Blow Tube	16
5.2. Pneumatic Adjustments	17
Control Valves	17
Throttle Valves at the Swing Cylinder	18
Throttle Valves at the Manifold	19
5.3. Selection of the Operation Mode	20
Operation Mode "Printing / Labelling"	20
Operation Mode "Labelling / Printing - Waiting in the Starting Position"	20
Operation Mode "Labelling / Printing - Waiting in the Transition Position"	21
Function of the Pre-dispense Key	22
Setting the Operation Mode and the Delay Times	24
Print Info Display	27
6. Operation	28
Appendix A - PLC-Interface	
Appendix B - Error Messages	
Appendix C - Function of the LED of the Applicator Electronic	
Index	
EC-Conformity Declaration	

1. Product Description

Function

The Tamp Applicator with Swing and Lift Cylinder is an extra device to use with the label printer for automatically applying the printed label onto the product. The applicator is equipped with a swing cylinder. This makes it possible to apply the labels at vertical areas.

The labels are transferred with a pad, which moves between the starting position and the labelling position, by two compressed-air driven pneumatic cylinders.

In the **starting position**, the label is picked up from the printer. The position of the pad in the starting position is signalized by a sensor. The label is removed from the carrier ribbon directly at the dispense edge of the printer. It is sucked on the pad by a vacuum via drillings at the bottom of the pad. For support, the label is also blown against the pad with an air current coming from a blow tube. The correct transfer from the label is controlled by a vacuum sensor. Next, the pad is moved by the swing cylinder into the **transition position**, which is confirmed by another sensor. Following the lift cylinder is pushed forwards and the pad is moved into the **labelling position**. Here, the label is pressed onto the product by the pad. Then the lift cylinder is moved back into the transition position. A sensor registers that the pad is in the transition position. Next the pad is swung into the starting position. While the pad is moving back into the starting position, the vacuum sensor controls whether the label has been removed from the pad. Specially adapted pads can be used for different label sizes.

The control unit of the applicator is connected with the printer on its SPI interface using the peripheral connector of the printer. For operation in a network system the applicator's PLC (programmable logic control) interface with potential free inputs and outputs can be used.

Positions of the Pad




Fig. 1 Positions of the Pad

Technical Data

	Apollo	Hermes
Label Width :	12 - 112 mm	8 - 112 mm
Label Height :	5 - 70 mm	5 - 80 mm
Air Pressure :	5 - 6 bar	5 - 6 bar
Turning Angle (Swing Cylinder) :	115°	115°
Lift Height (Lift Cylinder) :	10 mm	10 mm

Tamp Applicator with Swing and Lift Cylinder

2. Equipment Supplied




Fig. 2 Equipment Supplied

1 - Tamp Applicator with Swing and Lift Cylinder

Type 3200 for the Label Printer Apollo

incl. 4 Cylinder-head Screws

4 Washers

4 Spring Washers

incl. Pad Unit (customized)

Pad

Blow Tube

2 - Tamp Applicator with Swing and Lift Cylinder

Type 3200H for the Label Printer Hermes

incl. 2 Hinges

4 Screws

1 Knurled Screw

incl. Pad Unit (customized)

Pad

Blow Tube

3 - Service Unit (Option)

incl. 2 Screws

2 Washers

Other options on request !

3. Safety Instructions



CAUTION !

Make sure that the printer is disconnected from the power supply and the valve at the service unit as well as the shutoff valve at the applicator are closed, while installing the delivered components.



CAUTION !

In operation, moving parts are easily accessible. Therefore, keep long hair, loose clothes, and jewellery distant. Before any manipulations in those areas, close the shutoff valve.



CAUTION !

Do not try to manipulate or repair parts that are not described in the manuals of the tamp applicator or the printer.

4. Installation

Installing the Tamp Applicator on the Apollo




Fig. 4a Installation of the Tamp Applicator on the Apollo

1. Dismantle the casing of the manifold (2) by loosening the screws, two on the left and one on the right.
2. Fasten the applicator at the front of the **Apollo** using the four supplied screws (1) including the washers.
3. Plug the connector (3) of the applicator's electronic system in the peripheral port of the **Apollo**.
4. Reassemble the casing of the manifold.

Installing the Tamp Applicator on the Hermes




Fig. 4b Installation of the Tamp Applicator on the Hermes

1. Fasten the two hinges (2) included in the equipment on the Hermes using the supplied screws.
2. Hang the applicator with its two hinges (1) into the hinges (2) of the Hermes.
3. Turn the applicator towards the **Hermes** as far as necessary to plug the connector of the applicator-electronics into the peripheral connector for cab-applicators on the front of the printer.
4. Contact the connector (3) of the applicator-electronics to the peripheral connector (4) of the Hermes.




Fig. 4c Installation of the Tamp Applicator on the Hermes

5. Attach the applicator on the Hermes by screwing the knurled screw (2) into the hole (1).

Installing the Service Unit




Fig. 4d Installation of the Service Unit on the Apollo




Fig. 4e Installation of the Service Unit on the Hermes

1. Fasten the service unit (1) at the back of the **Apollo** and/or the **Hermes** using the washers and the screws.
2. Insert the tube of the service unit (2) into the push-in-T-fitting (3) at the external blow valve.
Insert tube firmly.

Connections




Fig. 4f Connections

1. Prepare the connections to the power supply and to the computer as described in the manual of the printer.
2. To contact the PLC interface use the 15-pin connector at the manifold (for further details see appendix A).
3. Make sure that the shutoff valve (5) is closed (lever at the valve is turned vertical).
4. The connector (2) for the compressed air supply is located at the service unit (1) at the rear of the printer. The connector is suitable for a 1/4" coupling plug (3).
5. The air pressure for operating the applicator has to be adjusted at the service unit (1).
 - Pull knurled knob (4) up.
 - Turn knob to tune required operating pressure (5-6 bar). By turning knob clockwise the pressure rises.
 - Push knob down.
6. Switch on the power supply of the printer.



NOTICE !

After switching on, the swing cylinder always rotates into the transition position. In this position the lift cylinder is pulled in.

After pressing the key or the key the swing cylinder moves into the starting position.

7. Open the shutoff valve. (5/ lever is turned horizontal)

5. Adjustments

All supplied label applicators have passed a previous run at the factory.

It may be useful to do some more fine tuning when the applicator is installed. This refers mainly to those parameters, which are significant as part of a networked system as well as pneumatic settings, which have an influence on the application rate.

5.1. Mechanical Adjustments

Angle of the Pad in the Starting Position




Fig. 5.1a Adjusting the Angle of the Pad in the Starting Position

In the position where the label is picked up (starting position), the pad (5) is swung towards the printer in a certain angle. This angle can be adjusted by sliding the stud (2).

The angle is optimized when, in the starting position, the rear edge of the pad (5) is located vertically above the dispense edge (4) without touching the ribbon shield (3).

Tamp Applicator with Swing and Lift Cylinder

1. Loosen the screws (1).
2. Move the stud (2) within the longish holes.
By sliding the stud up the pad swings close by the ribbon shield.
3. Tighten the screws (1).

Tamp Applicator with Swing and Lift Cylinder

Adjusting the Level and the Sides of the Cylinder Unit on the Apollo




Fig. 5.1b Level Adjustment / Side Adjustment on the Apollo

Side Adjustment

1. Loosen both bottom screws (4) on the rear side of the mounting plate (5) of the tamp applicator type 3200.
2. Move the cylinder unit (2) within the longish hole (3) until the dispensed label is aligned centrally to the pad.
3. Tighten the screws (4).

Level Adjustment

1. Loosen both upper screws (1) on the rear side of the mounting plate (5) of the tamp applicator type 3200.
2. Move the cylinder unit until in its upper (starting) position the pad (6) is located slightly above the dispense edge (7) of the Apollo.
The distance between the pad and the dispense edge is recommended to be around 1 mm.
3. Tighten screws (1).

Adjusting the Level and the Sides of the Cylinder Unit on the Hermes

Side Adjustment




Fig. 5.1c Side Adjustment on the Hermes

1. Loosen both screws (1) on the rear side of the mounting plate (3) of the tamp applicator type 3200H.
2. Move the cylinder unit within the longish hole (3) until the dispensed label is aligned centrally to the pad.
3. Tighten the screws (1).

Level Adjustment




Fig. 5.1d Level Adjustment on the Hermes

1. Loosen both screws (2) on the front side of the tamp applicator type 3200H.
2. Move the cylinder unit within the longish holes (1) until in its upper (starting) position the pad (3) is located slightly above the dispense edge (4). The distance between the pad and the dispense edge is recommended to be around 1 mm.
3. Tighten the screws (2).

Tamp Applicator with Swing and Lift Cylinder

Tuning the Blow Tube




Fig. 5.1e Tuning the Blow Tube on the Apollo

Vertical adjustment

- Loosen the screws (2).
- Shift the blow tube (3) as required.
- Tighten screws (2).

Turn around longitudinal axis (Change the direction of the air current)

- Hold the slotted screw (4) with a screwdriver and loosen the counter nut (1).
- Adjust the tube (3) until the air current is aligned with the dispense edge of the printer.
- Tighten counter nut.




Fig. 5.1f Tuning the Blow Tube on the Hermes

Turn around longitudinal axis (Change the direction of the air current)

- Hold the slotted screw (4) with a screwdriver and loosen the counter nut (1).
- Adjust the tube (3) until the air current is aligned with the dispense edge of the printer.
- Tighten counter nut.

5.2 Pneumatic Adjustments

Control Valves




Fig. 5.2a Control Valves

To reach the control valves, the casing of the manifold has to be removed. Therefore, loosen the screws at the cover, two on the left and one on the right.

That way, four electric switchable control valves for compressed air become accessible. For manual tuning, the valves can also be operated by integrated keys (1).

The functions of the valves are as explained below.

'Zylinder' (2 / swing cylinder) :

Two-way valve to control the swing cylinder.

When the valve is switched off the pad is kept in the starting position. Switching the valve on will move the pad into the transition position.

Normally the disconnection of the valve is controlled by a signal of a sensor which recognizes if the pad is in this position. When operated manually, there is no controlling by a sensor. The pad moves to the transition position and stays in that position until the key is released.

'Stützluft' (3 / supporting air) :

This valve controls the switch-on of the supporting air at the blow tube.

'Zylinder' (4 / lift cylinder) :

This valve controls the movement of the lift cylinder. When the valve is switched on the pad is moved into the labelling position.

'Vakuum' (5 / vacuum nozzle) :

This valve operates the vacuum nozzle and, consequently, controls the vacuum on the pad for picking up the label.

Tamp Applicator with Swing and Lift Cylinder

Throttle Valves at the Swing Cylinder




Fig. 5.2b Throttle Valves at the Swing Cylinder

The setting of the cylinder can be regulated via two throttle valves (1, 3). Those valves regulate the speed with which the compressed air escapes the two air containers.

The valves are adjustable by turning the throttle screws. Turning clockwise will close the valves.

A wider opening of the bottom valve (3) speeds up the pad moving from the starting position to the transition position, a wider opening of the top valve (1) accelerates the return movement.

A third throttle valve (2) limits the speed of the compressed air streaming into the bottom air container. By switching the machine on this valve damps the first movement of the pad into the starting position. At this time the top air container is empty, therefore, the setting of the top throttle valve (1) is ineffective to damp this movement.

Throttle Valves at the Manifold




Fig. 5.2c Throttle Valves at the Manifold

Throttle valve to regulate the supporting air (1)

With this, valve the supporting air to blow the label onto the pad can be adjusted.

Turn the throttle screw to adjust the valve. Turning clockwise will close the valve.

The valve has to be tuned in such a way, that the label is blown onto the pad without turning or swinging.

Throttle valve to regulate the vacuum (2)

With this, valve the vacuum to suck the label onto the pad can be adjusted.

Turn the throttle screw to adjust the valve. Turning clockwise will close the valve.

The vacuum can be adjusted until the label totally sticks on the vacuum plate.

5.3 Selection of the Operation Mode

The tamp applicator can be operated in three different ways referring to the order of printing and labelling of one applying cycle. A mode can be selected through actuating a DIP switch. All operating modes can be adjusted by setting different time delays. Furthermore, there is a special mode using the pre-dispense key for adjusting, etc.

Operation Mode 'Printing / Labelling'

The print of a label is released by an external start signal (via PLC interface). At the same moment the vacuum on the pad as well as the supporting air from the blow tube are switched on. When the label is printed and picked up from the carrier ribbon, the supporting air is switched off and the swing cylinder is driven in such a way that the pad is swung into the transition position. A sensor signals when the transition position is reached.

Following the lift cylinder is pushed forwards, the vacuum is switched off. The label is placed onto the product by the pad.

After that the lift cylinder is pulled in. A magnetic sensor signalizes the transition position of the lift cylinder. Next the swing cylinder is driven to move the pad back into the starting position. Thus, the labelling cycle is finished.

Operation Mode 'Labelling / Printing - Waiting in the Starting Position'

Before starting the mode 'labelling / printing' the printing and picking up of the first label has to be released separately by a special signal (via PLC interface).

The pad with the printed label is in the starting position. The vacuum on the plate is switched on.

By an external start signal, the swing cylinder is driven to swing the pad into the transition position. The sensor signals when the transition position is reached.

In the following the lift cylinder is pushed forwards and the vacuum is switched off. The label is placed onto the product by the pad. After that the lift cylinder is pulled in. A magnetic sensor signalizes the transition position of the lift cylinder. Next the swing cylinder is driven to move the pad back into the starting position. Now the next label is printed. At the same moment, the vacuum on the pad as well as the supporting air from the blow tube are switched on. When the label is printed and picked up from the carrier ribbon, the supporting air is switched off. Thus, the labelling cycle is finished.

Operation Mode 'Labelling / Printing - Waiting in the Transition Position'

This mode differs from the above described mode 'Labelling / Printing - Waiting in the Starting Position' in so far as the printed label is immediately moved into the transition position and is being held there. Consequently the next cycle begins by pressing the label onto the product.

Function of the Pre-dispense Key




Fig. 5.3a Pre-dispense Key

By pressing the pre-dispense key (1), half cycles of the labelling process can alternately be released, provided that there is a print job.

1(st) half cycle

Pressing the key will release the print of one label. At the same moment the vacuum at the pad as well as the supporting air (blow tube) are switched on. After the label has been printed and picked up by the pad, the supporting air is switched off.

2(nd) half cycle

Pressing the key will drive the swing cylinder to move the pad down into the transition position. The sensor signals when the transition position is reached.

Following the lift cylinder is pushed forwards, the vacuum is switched off. The label is placed onto the product by the pad. After that the lift cylinder is pulled in. A magnetic sensor signalizes the transition position of the lift cylinder. Then, the swing cylinder is driven to move the pad back into the starting position.

If the label is removed from the pad manually after the first half cycle of the labelling process, the print process will be repeated when the pre-dispense key is pressed again.

If there is no print job, only the movements of the pad as described for the second part of the labelling cycle are carried out, pressing the key.

The first half cycle of the labelling process can also be released by pressing the  key on the control panel of the printer. In that case, a blank label is picked up by the pad. That way, the whole labelling process can be simulated by alternately pressing the  key and the pre-dispense key without the need of a print job or a connection to a computer.

Setting the Operation Mode and the Delay Times




Fig 5.3b Potentiometers and DIP-Switches

For best adaptation, the applicator offers several methods to adjust to the whole system and, therefore, to the required needs. After removing the cover of the manifold, 6 potentiometers as well as 4 DIP switches become accessible by which the parameters can be set.

Potentiometers

Potentiometer 1 is sealed. Certain voltage settings are pre-adjusted from the factory and not to be changed by the user.

The potentiometers 2 - 6 offer the adjustment of the labelling process by changing certain time delays. If any one of the settings is changed the actual value is briefly shown in the printer display.

Potentiometer (2) : t_B - pressing-on time 0 ... 2.5 s

This potentiometer is used to set the time period of the lift cylinder for pressing the label onto the product.

Potentiometer (3) : t_{SA} - switch-off delay supporting air 0 ... 2.5 s

Delayed to the process of the label being picked up, the supporting air is switched off.

In many cases, after being picked up by the pad the label edge may still stick on the carrier ribbon. This may affect the accuracy of the label positioning or even cause faults in the labelling. Therefore, switching off the air blow delayed can be useful to separate the label from the carrier ribbon and neatly place the label on the surface of the pad.

Potentiometer (4) : s_{SE} - switch-on delay supporting air 0 ... 20 mm

The supporting air from the blow tube is not immediately switched on when the print of the label is released but delayed. The air is switched on, when the label has covered a certain distance s_{SE} .

This delay helps to prevent a turning or swinging at the front of the label and, consequently, avoids faults when the label is being picked up from the printer.

The parameter measures the distance covered by the label before the supporting air is switched on, and it is not dependent on the print speed. This way, the position of the label can be determined until the air is switched on.

Potentiometer (5) : t_{SP} - locking time 0 ... 2.5 s

All start signals coming in following the first start signal are ignored when they arrive within the locking time t_{SP} .

Potentiometer (6) : t_{VS} - start delay 0 ... 2.5 s

The parameter t_{VS} determines the time period between the start signal and the start of the labelling process. With this delay it is possible to release the start of the labelling process sensor controlled, for instance, when a sensor is located on an assembly line in front of the labelling place.

DIP Switches

With the DIP switches (7) the operation mode as well as the firmware of the applicator can be determined.

DIP-Switch	Parameter	ON	OFF
1	Waiting position in the operation mode Labelling/Printing (only DIP2 OFF and DIP3 OFF)	Starting Position	Transition Position
2	Applicator	has always to be OFF	
3	Operation mode	Printing / Labelling	Labelling / Printing
4	Save potentiometer settings	no	yes

If switch No. 4 is OFF the setting of the potentiometers is automatically stored in the printer when switched on. Therefore, in case the applicator has been changed (e.g. in case of an accident) the settings are still saved and can be transferred to a replacement (see also Print info display).

Print Info Display

Apollo and **Hermes** offer a convenient option for recalling information about the configuration and hardware problems in the printer info display (see also Operator's Manual of the printer).

First, press the  key to switch from ONLINE mode into OFFLINE mode. Next, to recall the printer information desired, press the  key to see the first of the five display pages available. Press this key repeatedly to view the other pages. When an applicator is installed, this display is extended by another five pages. After the standard pages, the following parameters are shown :

- start delay
- locking time
- switch-off delay supporting air
- pressing-on time
- switch-on delay supporting air.

When the reviewing is completed, switch back into ONLINE mode by pressing the  key.

In case the applicator has been changed (e.g. in case of an accident) the stored parameters can be viewed as described above and the new device can be adjusted accordingly. For that purpose the DIP-switch 4 at the new applicator has to be 'ON' during switching on the device the first time.

6. Operation

-  1. Check all external connections before starting to print.
2. Make sure that the media is loaded corresponding to the instructions of the Operator's Manual of the appropriate printer.
Apollo : chapter 'Options'
'Present Sensor/Inserting the Labels for Peel-off'
Hermes : chapter 'Media Loading'
'Loading Labels'
3. Check that the transfer ribbon is loaded properly before starting to print (see Operator's Manual of the printer).
4. Switch on the printer on the power switch.
Make sure that the pad is not covered by a label when switching on the device.

NOTICE !

After switching on, the swing cylinder always rotates into the transition position. In this position the lift cylinder is pulled in.

After pressing the  key or the  key the swing cylinder moves into the starting position.

5. Open the shutoff valve.
6. Switch into the present mode of the printer during programming and set the peel position to remove the labels from the carrier ribbon corresponding to the size of the label.

7. Before starting the first print job press the  key on the printer.

This generates a synchronous running. Remove the processed labels manually. After a few seconds the printer carries out a brief rewind and the edge of the next label is positioned at the print line.

This synchronizing also has to be carried out when the print job

has been interrupted with the  key.

8. Start the print job.
9. Start the labelling process via PLC interface.

If an error occurs while the applicator is operating, this is shown in the display of the printer (for types of errors and how to treat them see appendix B).

Tamp Applicator with Swing and Lift Cylinder

This page is intentionally left blank.

Appendix A - PLC Interface

For use in a networked system the applicator is equipped with a PLC interface to start and interrupt the labelling process. It also passes on state information as well as error messages of the applicator to the system control.

The interface has a 15 pin SUB-D connector.

Pin Assignment of the PLC Interface




Fig. A-1 Connector of the PLC Interface

PIN	Signal	Direction	Function
1	XSTRT	input	start signal
2	XSTP	input	stop signal
3	XDREE	input	print first label
4	XDNB	output	printer not ready
5	XEDG	output	no existing print job
6	XSAA	output	general error message
7	XSOE	output	pad in starting position
8	GND	output	grounding (0V)
9	XSTRTR	(input)	start signal (reverse line)
10	XSTPR	(input)	stop signal (reverse line)
11	XDREER	(input)	print first label (reverse line)
12	XSUE	output	pad in transition position
13	XETF	output	applicator fault
14	RÜL	output	reverse line (for all output signals)
15	24P	output	operating voltage +24V, Si T 100mA

Table A-1 Pin Assignment of the PLC Interface

Circuit Diagrams of Input and Output

The **inputs** are optocouplers with a current limiting resistor of $2.4\text{k}\Omega$ in the input circuit.

For each signal $X[\text{IN}]$ there is a separate reverse line $X[\text{IN}]\text{R}$ via the plug connector. From that, the following matching pairs of signals result :




Fig. A-2 Circuit of the Inputs

All **outputs** are realized through solid state relays which outputs are connected among one another one-sided. The joint line is lead to the plug connector as RÜL signal.

The switch function of the outputs is to open or close the contact between the joint line RÜL and the respective output.

Electrical requirements : $U_{\max} = 42V$
 $I_{\max} = 100mA$




Fig. A-3 Circuit of the Outputs

Comments on the Signals

PIN1 - XSTRT - Start signal

This signal will release the start of the labelling process. It is active when a current flows between PIN1 and PIN9.

PIN2 - XSTP - Stop signal

The signal is active when a current flows between PIN2 and PIN10.
It releases following functions :

- to finish the print of a label and its picking-up by the pad
- to interrupt or to stop the beginning of the labelling process
- to make the pad moving back into the starting position
- to command the disregard of all following signals
- if the stop signal has been activated during the labelling phase, the display will show the message 'Host stop/ error'. (does not show message during print process)

PIN3 - XDREE - Print first label

When current flows between PIN3 and PIN11 the print of the first label and its picking-up by the pad is released within the operation mode 'Labelling / Printing'.

When the labelling process is started by the XSTRT signal within the operation mode 'Labelling / Printing', the cylinder will start to place the label onto the product at once. Only after that, a new label is printed. Therefore, the provision of the first label has to be assigned by a separate signal.

In the 'Printing / Labelling' mode this signal has no function.

PIN4 - XDNB - Printer not ready

This is an error message of the printer.

The details and type of error can be learnt from the printer display.
('Ribbon out'; 'Paper out'; 'No label')

In this state the contact between PIN4 and PIN14 is opened.
After error correction, the print of the last label will be repeated.

PIN5 - XEDG - No existing print job

State message.

There is no print job currently available.

In this state the contact between PIN5 and PIN14 is opened.

PIN6 - XSAA - General error message

General error message of both, printer and applicator.

This message is shown when one of the two errors either XDNB or XETF occurs. This signal is important in case that only one error

signal of the applicator can be analysed from the system control.

In this state the contact between PIN6 and PIN14 is opened.

PIN7 - XSOE - Pad in starting position

The signal is active when the pad is in the starting position where it picks up the label from the printer.

In this state the contact between PIN7 and PIN14 is opened.

PIN8 - GND - Grounding (0V)

PIN9 - XSTRTR - Reverse line of the start signal XSTRT

PIN10 - XSTPR - Reverse line of the stop signal XSTP

PIN11 - XDREER - Reverse line of the print first label signal XDREE

PIN12 - XSUE - Pad in transition position

The signal is active when the pad is in its transition position.

In this state the contact between PIN12 and PIN14 is opened.

PIN13 - XETF - Applicator fault

This is an error message of the applicator.

This message is shown when one of the following errors occurs at the applicator :

- pad has not reached the transition position within 2s after the movement of the cylinder
- pad has not reached the starting position within 2s after the movement of the cylinder
- pad has not leaved the transition position within 2s after the signal to push forwards the lift cylinder has been given
- pad has not moved back to the transition position within a defined time by the lift cylinder
- a printed label has not been picked up by the pad properly or it fell down during the movement of the cylinder (message of the vacuum sensor)
- the label is still on the vacuum plate of the pad when the cylinder moves back up (message of the vacuum sensor)

The type of fault is shown in the display of the printer.

In this state the contact between PIN13 and PIN14 is opened.

After fault correction, the print of the last label printed before the fault occurred will not be repeated.

PIN14 - RÜL - Reverse line (for all output signals)

PIN15 - 24P - Operating voltage +24V, Si T 100mA



There is an operating voltage of 24V available on PIN15 provided from the applicator system.

CAUTION !

You must not apply any external voltage on PIN15 !




The operating voltage on the plug connector allows the use of the applicator without being part of a networked system. The start signal which is required for releasing the labelling process may be caused, for instance, by a suitable foot controlled switch with a 15 pin SUB-D plug.

Examples for Circuits to Creating a Start Signal**Fig. A-4 Example with releasing switch**

* dependent on the used sensor

Fig. A-5 Example for an optical sensor with pnp-output

Applicator - PLC Interface



* dependent on the used sensor

Fig. A-6 Example for an optical sensor with npn-output

Appendix B - Error Messages

Error Messages of the Printer

Detailed information about printer errors (e.g. 'Paper out', 'Ribbon out', etc.), their causes and correction methods can be found in the Operator's manual of the printer (Appendix C).



With the installation of an applicator the error treatment expands. This means in particular, that after correcting the error and **before** the correction is quit with the key, an additional label feed has to be released using the key. This synchronizes the process of printing and labelling. Possibly dispensed blank labels have to be removed manually.
After quitting the error message the label caused the error will be printed once more.

Error Messages of the Applicator

The following table gives an overview of error messages and their possible cause. It also suggests methods to resolve the problem.
After error correction, always quit the error message of the applicator with the key.

To reprint the label where the applicator error occurred, a new print job has to be released.

Applicator - Error Messages

Error message	Possible cause	Solution
Label not depos.	Label has not been placed onto the product; after the cylinder has moved back the label still sticks on the vacuum plate of the pad	Label the product manually
Upper position	Pad has not reached the starting position within 2s after the swing cylinder has moved back; or Pad has left the starting position unauthorized or Pad is not moved back to the transition position within a defined time by the lift cylinder	Check the pneumatic adjustments of the concerned cylinder (esp. the upper throttle valve of the swing cylinder); Label the product manually
Host stop / error	Labelling process has been interrupted by an XSTP stop signal via PLC interface	Label the product manually if necessary
Refl. sensor blk.	There has been no change of the switch state between the start of the labelling process and the signal from the labelling position sensor at the sensor which controls the starting position.	Check the sensor (service)
Vac. plate empty	Label has not been picked up properly by the pad; or Label fell off the pad before it could be placed onto the product	If possible, place the 'lost' label onto the product manually; Otherwise stop print job and start again with adapted parameters (e.g. count)
Lower position	Pad has not reached the transition position within 2s after the movement of the swing cylinder or Pad has left the transition position unauthorized or Pad has not leaved the transition position within 2s after the signal to push forwards the lift cylinder has been given	Check the pneumatic adjustments of the concerned cylinder (esp. the lower throttle valve of the swing cylinder) Check the applicator for heaviness of its mechanics; Label the product manually

Table B-1 Error Messages of the Applicator

Appendix C - Function of the LEDs of the Applicator Electronics

PLC Port PCB




Fig. C-1 LED on the PLC port PCB

LED No.	Colour	Function	Active state
1	green	PLC signal XSTRT	ON
2	green	PLC signal XSTP	ON
3	green	PLC signal XDREE	ON

Table C-1 LED on the PLC Port PCB

Applicator - Function of the LEDs of the Electronics

PCB Applicator Control




Fig. C-2 LED on the Applicator Control PCB

LED-Nr.	Colour	Function	Active state
4	red	Sensor signals that swing cylinder is in transition position	OFF
5	red	Sensor signals that swing cylinder is in starting position	ON
6	yellow	Label on the pad	ON
7	yellow	Operating voltage 5V	ON

Table C-2 LED on the applicator control PCB

Index

A

Air pressure 11
Applicator control C-2
Applicator fault A-6

B

Blow tube 4, 6, 16f., 20f.

C

CAN key (Printer) 11, 28
Casing manifold 8, 17
Compressed air supply 11
Connections 11, 28
Control valves 17
Copyright 2

D

Delay times 24
DIP switches 20, 26f.

E

Equipment supplied 6
Error messages B-1f.
Error messages applicator B-1f.
Error messages printer B-1
Errors 28

F

FF key (Printer) 23, 28, B-1

G

General error message A-5

H

Host stop / error A-4, B-2

L

Labelling position 4f., 17
Labelling / Printing 20, 26
Label not deposited B-2
LED C-1f.
Level adjustment 14f.
Lift cylinder 4f., 11, 17, 20f., 24,
A-6, B-2
Locking time 25, 27
Lower position B-2

M

Manifold 8, 11, 17, 19, 24

N

No existing print job A-5

O

ONL key (Printer) 27
Operating pressure 11
Operation modes 20f., 24

P

Pad 4f., 12f., 17ff., A-6, B-2, C-2
Pad holder 5, 12
Pad in transition position A-1, A-5
Pad in starting position A-1, A-5
Pad unit 6
Peripheral port (Printer) 8, 9
PLC 28
PLC-connection C-1
PLC interface 4, 11, 20, A-1ff
Pneumatic cylinder 4
Potentiometer 24f.
Pre-dispense key 22f.
Pressing-on time 24, 27
Printer not ready A-4
Print first label A-4
Print info display 27
Printing / Labelling 20, 26
PSE key (Printer) 11, 27f., B-1

Tamp Applicator with Swing and Lift Cylinder

R

Ribbon shield (Printer) 12f.
Reflective sensor blocked B-2

S

Safety instructions 7
Save settings 26
Service unit 6, 7, 10f.
Shutoff valve 7, 11, 28
Side adjustment 14f.
Signals (PLC) A-1f., C-1
SPI interface 4
Start delay 25, 27
Starting position 4f., 11f., 17, 20, 26,
A-6, B-2, C-2
Start signal A-4
Stop signal A-4
Stud 12f.
Supporting air 4, 16f., 19ff.
Swing cylinder 4, 11, 17f., 20f., 28,
A-6, B-2
Switch-off delay supporting air 25, 27
Switch-on delay supporting air 25, 27

T

Technical data 5
Throttle valves 18f.
Transition position 4f., 17f., 20f., 28,
A-5, B-2

U

Upper position B-2

V

Vacuum 4, 17 19f.
Vacuum nozzle 17
Vacuum plate empty B-2
Vacuum sensor 4



Gesellschaft für Computer-
und Automations-
Bausteine mbH & Co KG
Wilhelm-Schickard-Straße 14
D-76131 Karlsruhe

EC-Conformity Declaration

Herewith we declare that the following described machine, from the design and style and as we sell it, complies with the relevant EC Safety and Health Requirements.

This declaration will lose the validity if there are any changes of the machine or the purpose without our consent.

Description:
Applicator

Type:
**Tamp Applicator
with Swing and Lift Cylinder**

Applied EC Regulations and Norms:

- EC-Machinery Directive	98/37/EU
- Machine Safety	EN 292-2:1991 + A1:1995
- EC Low Voltage Regulations	73/23/EEC
- Data and Office Machine Safety	EN60950:1992 + A1:1993 EN 60950/A2:1993 + A3:1995 + A4:1997
- EC Electromagnetic Compatibility Regulations	89/336/EEC
- Threshold values for the Interference of Data Machines	EN 55022:1998
- Limits for harmonic current emission	EN 61000-3-2:1995 + A1:1998 + A2:1998 + A14:2000
- Limits of voltage fluctuation and flicker	EN 61000-3-3:1995
- Immunity characteristics- Limits and methods of measurement	EN 55024:1998

Signature for the producer:

cab Produkttechnik Sömmerna
Gesellschaft für Computer-
und Automationsbausteine mbH
99610 Sömmerna

Sömmerna, 15.07.03

Erwin Fascher
Managing Director