


Technical Information



Integration FL+ into FL Peripherals

(not applicable to THS+Basic, THS+M and LSG+65)

Art.-No.: 9009865

1	Preface	4
2	Introduction	5
2.1	Notes	5
3	Instructions	6
3.1	FL-PCI	6
3.2	FL-TCP	6
3.3	E-Stop wiring for FL+	6
4	Pinout CON 4 - E-Stop Circuit	7
4.1	Pinout FL E-Stop – CON4	7
4.2	Pinout FL+ E-Stop – CON4.....	8
5	Example Wiring FL+ E-Stop	9
5.1	E-Stop and Interlock with Feedback Contact	9
5.2	E-Stop and Interlock without Feedback Contact	10
6	Enclosures	11
6.1	Section of Data Sheet Safety Relais (Dold Co.).....	11
7	Reference Documents	12

Edition: 2018/08 - Art.-No. 9009865

Copyright

This documentation as well as translation hereof are property of cab Produkttechnik GmbH & Co. KG.

The replication, conversion, duplication or divulgement of the whole manual or parts of it for other intentions than its original intended purpose demand the previous written authorization by cab.

Any software being part of this system is made available under license and may become use or be copied only in agreement with the license conditions.

Trademark

Microsoft® is a registered trademark of the Microsoft Corporation.

Windows XP®, Windows 7®, Windows 8® are registered trademarks of the Microsoft Corporation.

TrueType™ is a registered trademark of Apple Computer, Inc.

Editing

For questions or comments please contact cab Produkttechnik GmbH & Co. KG.

Author

Sonia Hiss, cab Produkttechnik GmbH & Co. KG

Topicality

Due to steady new developments of our products differences between documentation and product may occur. Please refer to www.cab.de for the latest version.

Terms and Conditions

Deliveries and services are rendered on the basis of the "General Terms and Conditions" of cab.

Germany

cab Produkttechnik GmbH & Co KG
Karlsruhe
Tel. +49 721 6626 0
www.cab.de

USA

cab Technology, Inc.
Chelmsford, MA
Tel. +1 978 250 8321
www.cab.de/us

Taiwan

cab Technology Co., Ltd.
Taipeh
Tel. +886 (02) 8227 3966
www.cab.de/tw

China

cab (Shanghai) Trading Co., Ltd.
Guangzhou
Tel. +86 (020) 2831 7358
www.cab.de/cn

France

cab Technologies S.à.r.l.
Niedermodern
Tel. +33 388 722501
www.cab.de/fr

Mexico

cab Technology, Inc.
Juárez
Tel. +52 656 682 4301
www.cab.de/es

China

cab (Shanghai) Trading Co., Ltd.
Shanghai
Tel. +86 (021) 6236 3161
www.cab.de/cn

South Africa

cab Technology (Pty) Ltd.
Randburg
Tel. +27 11 886 3580
www.cab.de/za

2.1 Notes

Important information and instructions are designated as follows:

**Danger!**

Draws attention to an exceptionally great, imminent danger to your health or life due to hazardous voltages.

**Danger!**

Draws attention to a danger with high risk which, if not avoided, may result in death or serious injury.

**Warning!**

Draws attention to a danger with medium risk which, if not avoided, may result in death or serious injury.

**Caution!**

Draws attention to a danger with low risk which, if not avoided, may result in minor or moderate injury.

**Attention!**

Draws attention to potential risks of property damage or loss of quality.

**Note!**

Advices to make work routine easier or on important steps to be carried out.

**Environment!**

Advices on protecting the environment.



Handling instructions



Reference to chapter, position, picture number or document.



Option (accessories, peripherals, extras).

Time Viewed in the display / monitor.

Instructions to exchange the FL marking laser by the FL+ marking laser within an existing peripheral system. I/O- and Remote cable need to be exchanged and E-Stop / Interlock wiring (refer to chapter 5) have to be adapted.

3.1 FL-PCI:

5527478 Adaptercable set FL-PCI/FL+, consisting of:

- Adapter cable User I/O CON2 FL-PCI/FL+ 0,3 meter
- Adapter cable Remote CON3 FL/FL+ 0,3 meter

3.2 FL-TCP:

5527479 Adapter cable set FL-TCP/FL+, consisting of:

- Adapter cable User I/O CON2 FL-TCP/FL+ 0,3 meter
- Adapter cable Remote CON3 FL/FL+ 0,3 meter

3.3 E-Stop Wiring for FL+

Two versions are possible:

- Integration E-Stop and Interlock **with** feedback contact (chapter 5.1)
- Integration E-Stop and Interlock **without** feedback contact (chapter 5.2)



Note!

The FL+ has no E-Stop at the front panel. Wiring may, as described in Chapter 5, be realized. Alternatively, it is sufficient to integrate the FL+ marking laser into an existing E-Stop circuit.

4.1 Pinout FL E-Stop – CON4




Figure 1: FL Interface Interlock / E-Stop (Sub-D socket 9 pole)

PIN	Description ICL/E-Stop CON4	Remark	Correlation	Current	Function
1	E-Stop IN	E-Stop Circuit Input	●	potential free	NC
2	E-Stop OUT	E-Stop Circuit Output	●●	potential free	NC
3	Not Used				
4	Interlock 1	Safety Interlock 1	●●●	potential free	NO
5	Interlock 2	Safety Interlock 2	●●●●	potential free	NO
6	E-Stop IN	E-Stop Circuit Input	●	potential free	NC
7	E-Stop OUT	E-Stop Circuit Output	●●	potential free	NC
8	Interlock 1	Safety Interlock 1	●●●	potential free	NO
9	Interlock 2	Safety Interlock 2	●●●●	potential free	NO

Table 1: Pinout Interface FL Interlock / E-Stop

4.2 Pinout FL+ E-Stop – CON4




Figure 2: FL+ Interface Interlock / E-Stop (Sub-D socket 9 pole)

Pin	Name	Description	Activation / active
1	FP24V	Internal operating voltage +24 V, max. 500 mA	
2	E-Stop signaling contact connection A	Status of E-Stop relay' Device ready for operation when signal active	Contact between Pin 2 and Pin 7 is open, if the E-Stop is not activated, i.e. the E-Stop relay is not current fed
3	Interlock Signaling contact connection A	Status of Interlock-Relay' Device ready for operation when signal active	Contact between Pin 3 and Pin 8 is open, if the safety circuit is closed, i.e. the Interlock relay is current fed
4	Interlock IN	Interlock relay Connection for safety switch Device ready for operation when signal active	Active, if connected to +24V between Pin 4 and Pin 9
5	GND INT	0 V intern	
6	E-Stop IN	Emergency Stop relay Connection for E-Stop Device ready for operation when signal active	Active, if connected to +24V between Pin 6 and Pin 9
7	E-Stop signaling contact connection B	Status of E-Stop relay' (return circuit)	▷ Pin 2
8	Interlock signaling contact connection B	Status of Interlock relay' (return circuit)	▷ Pin 3
9	GND EXT	Common GND potential for Interlock IN and E-Stop IN	

Table 2: Pinout Interface FL+ Interlock / E-Stop

5.1 E-Stop and Interlock with Feedback Contact

Single-channel E-STOP circuit. There is no redundancy in the E-Stop control circuit.




Figure 3: Wiring diagram E-Stop and Interlock with feedback contact

5.2 E-Stop and Interlock without Feedback Contact




Figure 4: Wiring diagram E-Stop and Interlock without feedback contact

6.1 Section of Data Sheet Safety Relais (Dold Co.)




Figure 5: Block diagram safety relays from Dold 5925

Position	Description
1	Assembly Instructions Marking Laser FL
2	Assembly Instructions Marking Laser FL+
3	Data Sheet Safety Relais Dold: http://de.dold.com/datenblaetter/Schaltgeraete/LG5925_de.pdf