


Instructions

Label File Selection Box - Input/Output Box (Part No. 5948205)

Edition: 04/2023 · Part No. 9009872



The box can be operated in two basic functions depending on the setting of the switch (2):
 Setting 00-15, 16-31 or ESC
 Setting I/O:

**Label file selection box
Input/output box**

Label File Selection Box

Function

With the label file selection box 16 different print jobs can be selected via PLC interface. The corresponding J-Script data must be filed on a memory medium in the printer.

System Requirements

Printer of the series SQUIX, A+, XC Q, XD Q, MACH 4, EOS, HERMES Q, Hermes+, PX Q or PX.

Pin Assignment of the 25-pin Plug

Pin	Signal	Pin	Reverse line	Direction	Function
1	D0	14	RD0	Input	Selection value 1
4	D1	17	RD1	Input	Selection value 2
7	D2	20	RD2	Input	Selection value 4
9	D3	22	RD3	Input	Selection value 8
12	STROBE	25	RSTROBE	Input	Validity signal

- Each input signal D0-D3 and STROBE has a separate reverse line.
- The particular signal is active when between [Signal] and the respective [Reverse line] +24 V is applied with (+) at [Signal].
- The circuits of the inputs cause a potential separation.

Operation


- Store up to 32 label files named E0.LBL up to E15.LBL in the path \LABELS of the memory medium.
- Insert the memory medium in the printer.
- Select setting "00-15", "16-31" or "ESC" at the switch (2).

Setting	00-15	16-31	ESC
File names and contents	E0 - E15 User-defined content	E16 - E31 User-defined content	E0 - E6 pre-defined E0 ESC!ESC! Hardware reset E1 ESCc Cancel current print job E2 ESCf Label feed E3 ESCt Cancel all print jobs E4 ESCp0 Pause OFF E5 ESCp1 Pause ON E6 ESC< Backfeed behind the label sensor E7 - E15 User-defined content

- Switch off the printer.
- Connect the box (1) to a USB master interface of the printer.
- Connect the 25-pin SUB-D plug of the box (1) to the PLC interface using a suitable cable.
- Switch on the printer.
- Select the designated file **Ex** via PLC by activating the binary-coded selection signals:

Setting "00-15" or "ESC" $x = D3*8 + D2*4 + D1*2 + D0$ Example: With D3 and D1 the file E10.LBL is selected.
 Setting "16-31" $x = 16 + D3*8 + D2*4 + D1*2 + D0$ Example: With D3 and D1 the file E26.LBL is selected.

- Confirm the selection via PLC by activating the signal STROBE for at least 50 ms.



Input/Output Box

Function

The input/output box allows to realize simple PLC procedures. Using abc-programming the printer can read four inputs and set four outputs. That allows the communication with other devices. In the programming a separate bit is assigned to each input and output (▷ Programming Manual). The abc-programming must be especially designed for the particular application.

System Requirements

Printer of the series SQUIX, A+, XC Q, XD Q, MACH 4, EOS, HERMES Q, Hermes+, PX Q or PX.

Pin Assignment of the 25-pin Plug

Pin	Signal	Pin	Reverse line	Direction	Function
1	E0	14	RE0	Input	Input bit 0
4	E1	17	RE1	Input	Input bit 1
7	E2	20	RE2	Input	Input bit 2
9	E3	22	RE3	Input	Input bit 3
15	A0			Output	Output bit 0
18	A1	24	24V_EXT	Output	Output bit 1
21	A2			Output	Output bit 2
23	A3			Output	Output bit 3
		6	GND_EXT		External Ground

- For the operation of the outputs 24V must be applied between Pin 24 and Pin 6.
- Each input signal E0-E3 has a separate reverse line.
- The particular signal is active when between Ex and REx +24 V is applied with (+) at Ex.
- All output signals A0-A3 have the common line 24V_EXT.
- When an output bit is set to "high" there is a low-resistance connection between Ax and 24V_EXT.
- The inputs and output circuits cause a potential separation.

EU Declaration of Conformity

▷ <https://www.cab.de/media/pushfile.cfm?file=2761>



Operation

- Select setting "I/O" at the switch (2).
- Switch off the printer.
- Connect the box (1) to a USB master interface of the printer.
- Connect the 25-pin SUB-D plug of the box (1) to the PLC interface using a suitable cable.
- Switch on the printer.
- Send a print job containing an abc-program to control the external device.

Germany
cab Produkttechnik GmbH & Co KG
 Karlsruhe
 Phone +49 721 6626 0
www.cab.de

France
cab Technologies S.à.r.l.
 Niedernmodern
 Phone +33 388 722501
www.cab.de/fr

USA
cab Technology, Inc.
 Chelmsford, MA
 Phone +1 978 250 8321
www.cab.de/us

Mexico
cab Technology, Inc.
 Juárez
 Phone +52 656 682 4301
www.cab.de/es

Taiwan
cab Technology Co., Ltd.
 Taipei
 Phone +886 (02) 8227 3966
www.cab.de/tw

China
cab (Shanghai) Trading Co., Ltd.
 Shanghai
 Phone +86 (021) 6236 3161
www.cab.de/cn

Singapore
cab Singapore Pte. Ltd.
 Singapore
 Phone +65 6931 9099
www.cab.de/en

South Africa
cab Technology (Pty) Ltd.
 Randburg
 Phone +27 11 886 3580
www.cab.de/za