

Assembly Instructions



Flag Applicator

4712

2 Assembly Instructions for the following product

2

Family	Type
Flag Applicator	4712L-300

Edition: 03/2020 - Part No. 9009954

Copyright

This documentation as well as translation hereof are property of cab Produkttechnik GmbH & Co. KG.

The replication, conversion, duplication or divulgement of the whole manual or parts of it for other intentions than its original intended purpose demand the previous written authorization by cab.

Editor

Regarding questions or comments please contact cab Produkttechnik GmbH & Co. KG.

Topicality

Due to the constant further development of our products discrepancies between documentation and products can occur. Please check www.cab.de for the latest update.

Terms and conditions

Deliveries and performances are effected under the General conditions of sale of cab.

Germany
cab Produkttechnik GmbH & Co KG
Karlsruhe
Phone +49 721 6626 0
www.cab.de

USA
cab Technology, Inc.
Chelmsford, MA
Phone +1 978 250 8321
www.cab.de/us

Taiwan
cab Technology Co., Ltd.
Taipei
Phone +886 (02) 8227 3966
www.cab.de/tw

China
cab (Shanghai) Trading Co., Ltd.
Guangzhou
Phone +86 (020) 2831 7358
www.cab.de/cn

France
cab Technologies S.à.r.l.
Niedermörsen
Phone +33 388 722501
www.cab.de/fr

Mexico
cab Technology, Inc.
Juárez
Phone +52 656 682 4301
www.cab.de/es

China
cab (Shanghai) Trading Co., Ltd.
Shanghai
Phone +86 (021) 6236 3161
www.cab.de/cn

South Africa
cab Technology (Pty) Ltd.
Randburg
Phone +27 11 886 3580
www.cab.de/za

1	Introduction	4
1.1	Instructions.....	4
1.2	Intended Use.....	4
1.3	Safety Instructions.....	4
1.4	Safety Markings	5
1.5	Environment.....	5
2	Product Description.....	6
2.1	Important Features.....	6
2.2	Technical Data.....	6
2.3	Product Overview.....	7
2.4	Contents of Delivery.....	8
3	Implementing.....	9
3.1	Required Space	9
3.2	Tools for the implementing	9
3.3	Mounting the Applicator.....	10
3.4	Mounting and Demounting the Cover	11
3.5	Releasing the Transportation Lock.....	11
3.6	Configuration on the Printer	12
3.6.1	Method for Changing the Printer Setup.....	12
3.6.2	Configuration Parameters of the Applicator.....	13
3.7	Compressed Air Connection	14
3.8	Test motion sequence and sensors.....	14
3.9	Mounting the Suction Pads	15
3.10	Mounting the Blow Tube.....	15
3.11	Preparing the Tamp Assembly for Adjustments.....	16
3.12	Adjusting the Pad	17
3.12.1	Moving the Pad in Y-Direction	18
3.12.2	Moving the Pad in Z-Direction	19
3.12.3	Moving the Pad in X-Direction.....	20
3.13	Setting the Peel Position.....	21
3.14	Activation of Peel-off Mode	21
3.15	Adjustments to the Blow Tube (Supporting Air).....	22
3.16	Adjusting the Vacuum	23
3.17	Alignment of the Product to the Applicator	24
3.18	Setting the Application Height	25
4	Operation	26
4.1	Test Mode without a Print Job	26
4.2	Test Mode with a Print Job	26
4.3	Standard Operation.....	27
4.4	Cleaning	27
5	Error Messages	28
5.1	Error Messages of the Printer	28
5.2	Error messages of the applicator	28
6	Licenses.....	29
6.1	Declaration of Incorporation.....	29
6.2	EU Declaration of Conformity.....	30

1.1 Instructions

Important information and instructions in this documentation are designated as follows:



Danger!

Draws attention to an exceptionally great, imminent danger to your health or life due to hazardous voltages.



Danger!

Draws attention to a danger with high risk which, if not avoided, may result in death or serious injury.



Warning!

Draws attention to a danger with medium risk which, if not avoided, may result in death or serious injury.



Caution!

Draws attention to a danger with low risk which, if not avoided, may result in minor or moderate injury.



Attention!

Draws attention to potential risks of property damage or loss of quality.



Note!

Advice to make work routine easier or on important steps to be carried out.



Environment!

Gives you tips on protecting the environment.



Handling instruction



Reference to section, position, illustration number or document.



Option (accessories, peripheral equipment, special fittings).

Time

Information in the display.

1.2 Intended Use

- The device is manufactured in accordance with the current technological status and the recognized safety rules. However, danger to life and limb of the user or third parties and/or damage to the device and other tangible assets can arise during use.
- The device may only be used for its intended purpose and if it is in perfect working order, and it must be used with regard to safety and dangers as stated in the manual.
- The device is designed to use on a cab printer of the HERMES Q series. Any other use or use going beyond this shall be regarded as improper use. The manufacturer/supplier shall not be liable for damage resulting from unauthorized use; the user shall bear the risk alone.
- Usage for the intended purpose also includes complying with the manual.



Note!

The complete and current version of the documentation can be found in the Internet.

1.3 Safety Instructions



Attention!

Initiation, adjustments and changing of parts are to be performed by qualified service personnel only.




Warning!

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

- Before mounting the delivered components disconnect the printer from the power supply and close the shutoff valve of the applicator.
- Only connect the device to other devices which have a protective low voltage.
- Switch off all affected devices (computer, printer, accessories) before connecting or disconnecting.
- In operation, moving parts are easily accessible.
This applies especially for the zone, where the pad is moved between the starting and the labelling position.
During operation do not reach into that zone and keep long hair, loose clothes, and jewelry distant. Before any manipulations in those areas, close the shutoff valve.
- The device may only be used in a dry environment, do not expose it to moisture (sprays of water, mists, etc.).
- Do not use the device in an explosive atmosphere.
- Do not use the device close to high-voltage power lines.
- Perform only those actions described in this manual.
Work going beyond this may only be performed by trained personnel or service technicians.
- Unauthorized interference with electronic modules or their software can cause malfunctions.
- Other unauthorized work on or modifications to the device can also endanger operational safety.
- Always have service work done in a qualified workshop, where the personnel have the technical knowledge and tools required to do the necessary work.
- There are various warning stickers on the device. They draw your attention to dangers. Warning stickers must therefore not be removed, as then you and other people cannot be aware of dangers and may be injured.

1.4 Safety Markings



Risk of injuries by moving parts!



The cylinder is under pressure
also if the printer is switched off.
Possibility of residual energy!



Danger of crushing hands and
fingers by the moving pad!



Attention!
Never remove or cover safety markings!
Replace it in case of damage!

Fig. 1 Safety marking

1.5 Environment



Obsolete devices contain valuable recyclable materials that should be sent for recycling.

- Send to suitable collection points, separately from residual waste.

The modular construction of the applicator enables it to be easily disassembled into its component parts.

- Send the parts for recycling.

2.1 Important Features

- The supporting air and the vacuum as well as the speed of the cylinder are adjustable. That way the applicator can be adapted to different label materials and sizes.
- For operation within a system the I/O interface of the printer can be used.

2.2 Technical Data



Fig. 2 Applicator parameters

Label transfer method		Form-pad
Label width in mm for	HERMES Q4	60 - 100
Label height in mm		10 - 50
Diameter in mm		3 - 16
Compressed air pressure		0,45 MPa (4,5 bar)
Sound pressure level		unter 74 dB(A)
Product during labeling	fixed	■
	in motion	-
Labeling onto the product	from top	■
	from below	■
	vertically rotated	0 - 180° clockwise; others on request
	from the side	■
Product height	fixed	■
	variable	-
Product distance to lower edge at cylinder stroke	min. mm	70
	300 mm up to mm	260
Immersion depth tongs	mm	55
Offset P	up to mm	1,0 ²⁾
Cycle time about frequency/min. ¹⁾		15

¹⁾ Determined at print speed 100 mm/s.

²⁾ Depending on the label quality.

Table 1 Technical data

2.3 Product Overview





Fig. 3 Product Overview

- | | |
|---------------------------------------|---------------------------|
| 1 Cover | 6 Cylinder peel position |
| 2 Compressed air connector | 7 Compact cylinder Pliers |
| 3 Shutoff valve | 8 Tamp group |
| 4 Short stroke cylinder - tamp / flag | 9 Blow tube |
| 5 Main stroke cylinder | 10 Pair of tamps |

2.4 Contents of Delivery



- Applicator with mounted tamp assembly (1)
- Adjustment tool for the tamps (2)
- Blow tube for supporting air (3)
(depend of the used printer)
- Air pressure regulation unit (4)
- Documentation and test protocol




Fig. 4 Content of Delivery



Note!

Please keep the original packaging in case the applicator must be returned.



Attention!

The device and printing materials will be damaged by moisture and wetness.

► Only set up the label printer with applicator in dry locations protected from moisture and splashes.

3.1 Required Space










Fig. 5 Disengaging or pivoting the applicator

3.2 Tools for the implementing

Screwdriver with parallel blade	2.5		To adjust the throttle valves and product sensor
Hexagon key L-wrench	0.8		To adjust the sensors (in contents of delivery)
	2.5		For matched norm parts (in contents of delivery)
	4		Pad adjustments Changing pad
Flat-round nose	straight		To mount/dismount tubes
	angled		
Open spanner	SW 5.5 90°		To change the pliers aperture
	SW 8		To change the throttle valves
	SW 13		Setting the spring power on the adapter bolt
	SW20		Changing the cylinder
Adjustment tool for the tamps	cab part No.: 597285		Mounting the tamps

3.3 Mounting the Applicator




Fig. 6 Mounting applicator on printer



Attention!

Initiation, adjustments and changing of parts is only for qualified service personal only.

▷ Service Manual

Mount the applicator

1. Hang the applicator with the female part of hinges (1) at the printer mounted hinges parts (2).
2. Connect SUB-D 15 male connector (6) to the female connector (7) of the printer.
3. To prevent the applicator from slipping out of the hinges loosen screw (4) and move the locking plate (3) under the hinges and tighten screw (4).
4. Swing the applicator to the printer and tighten the thumbscrew (5).
5. Keep the external compressed air supply closed and close the shut-off valve (10) on the applicator ▷ see illustration
6. Insert external compressed air supply (8) into the plug connector (9) on the shut-off valve (10).
7. Switch on compressed air and open shut-off valve (10) by turning 90 °.

For cleaning the applicator and printer it's sometime necessary to turn away or/and dismount the applicator. Don't change the adjustments of setting screws, throttle valves or other.

Turn away/Dismount the applicator

8. To turn away the applicator loosen thumbscrew (5) and swing the applicator aside.
9. Disconnect SUB-D 15 male connector (6) to the female connector (7) of the printer.
10. Loosen screw (4) and move off the locking plate (3) from the hinges.
11. Lift the applicator upward.

3.4 Mounting and Demounting the Cover


To initialize the applicator or perform adjustments it is required to remove the cover. Once content with the changes reattach the cover.



Warning!

It is only permitted to use the applicator with a mounted cover (2).

Only in the case of servicing, adjustments and maintenance may the cover be removed.



1. Loosen the screw (3).
2. Lift off the cover upward (2).
3. Once the service or maintenance has been completed lower the cover over the cylinder.
4. Guide cylinder (1) through the hole in the cover (2).
5. Tighten the screw (3) to fix the cover (2) in place.


Fig. 7 Cover

3.5 Releasing the Transportation Lock

Before the applicators are delivered, a transportation lock (4) is mounted on the rod (1).

For the labeling operation, the transport lock (4) is pushed onto the stopper (2).

The stopper (2) brakes the lifting movement and triggers the flag formation.



Releasing the transportation lock

1. Loosen the screw (3) of the transport lock (2).
2. Move the transport lock (4) on the rod (1) to the stopper (2).
1. Tighten the screw (3) of the transport lock (2) to fix the position.

If the position of the stopper (2) is changed to change the application height, the transport lock (4) must also be moved.

▷ „3.18 Setting the Application Height“

Fig. 8 Transportation Lock

3.6 Configuration on the Printer

The method of use of the applicator can be modified by altering the parameter settings.

The most important setting is the choice between the mode "stamp" and "blow." Besides that the applicator has different sequences of printing and applying labels in a labeling cycle.

The flag applicator will activate in the mode of operation *Blow* pursued around all necessary parameters and to be able to modify.

The application modes can be further modified by delay settings.



Note!

For detailed information about the printer configurations and functions of the buttons

▷ **Configuration manual** respectively ▷ **Operator's Manual of the printer**

3.6.1 Method for Changing the Printer Setup

1. Press **menu** button.
2. Menu



Setup>



Labelling >

3. Select and adjust the needed parameters.
4. Return to the "Ready" mode.

3.6.2 Configuration Parameters of the Applicator

► Start menu.

► Select  Setup >  Labelling.














Parameter	Meaning	Default
 <i>Transfer mode</i>	Setting the operation mode <i>Blow on</i>	<i>Blow on</i>
 <i>Cycle sequence</i>	Setting the application mode <i>Print-Apply</i> : An external start signal releases the print of a label and following the application of the label. After a cycle is complete, the pad without label waits in the start position. <i>Apply-Print</i> : An extra signal starts the print of the first label and the transfer of the label to the pad. The external start signal releases the application of the label and following the print and transfer of the next label. After a cycle is complete, the pad with a label is in the waiting position.	<i>Print-Apply</i>
 <i>Waiting position</i>	Only for <i>mode = Blow on</i> and <i>Cycle sequence = Apply-Print</i> <i>up</i> : Pad waits in the start position for the start signal <i>down</i> : Pad waits in the labelling position for the start signal	<i>up</i>
 <i>Blow time</i>	Controls how long the tamps with the suction plates are pressed together.	<i>200 ms</i>
 <i>Support delay on</i>	Setting the switch-on delay (max. 2,5 s) for the supporting air between print start and switching on the supporting air. The delay prevents swirling at the front of the label and, consequently, avoids faults when the label is being picked up from the printer.	<i>0 ms</i>
 <i>Support delay off</i>	Setting the switch-off delay (max. 2,5 s) for the supporting air between the end of label forwarding and switching on the supporting air. The delay can be useful to separate the rear edge of the label from the carrier to avoid errors and to improve the accuracy of label positioning	<i>270 ms</i>
 <i>Start delay</i>	Delay (max. 2,5 s) between start signal and the start of an labelling cycle. Allows e.g. the use of product sensors at conveyors.	<i>0 ms</i>
 <i>Lock time</i>	Controls the time from the start of flag formation until the pliers open	<i>250 ms</i>
 <i>Vacuum delay</i>	<i>On</i> - The vacuum will be switched on after the label feed is completed. <i>Off</i> - The vacuum will be switched on when the label feed starts.	<i>Off</i>
 <i>Vacuum control</i>	Setting the label transfer check from printer to pad and from pad to product by the vacuum sensor	<i>On</i>
 <i>Label hand-over</i>	<i>Passive</i> - The pad waits in front of the dispense edge for the label. <i>Active</i> - The pad moves to the dispense edge and takes the label.	<i>Passive</i>
 <i>Cleaning blow</i>	Activation of a short blow impulse after the application of the label to clean the suction channels.	<i>On</i>
 <i>Peel-off position</i>	Shift the position of the dispensed label relative to the dispensing edge. The setting can also be adjusted by the software. The settings of configuration and software are added together.	<i>0.0 mm</i>

Table 2 Parameters of the Setup > Labelling menu

3.7 Compressed Air Connection



Attention!


Adjustments and functionality control were done with a compressed air value of 4.5 bar.
The applicator's operating range is between 4.0 and 6.0 bar.



Warning!

When connecting the applicator to compressed air it is considered "IN USE!" Cylinder motion is possible!

► Do not reach into the zone of the moving pad and keep long hair, loose clothes, and jewelry away.



1. Check that the stop valve (2) is closed as illustrated.
2. Attach compressed air to connector (1).
3. Open the stop valve (2) by turning it into the direction of air flow.
4. Switch on the printer via the power switch.

A pressure regulation unit (3) must be connected upstream to stabilize the compressed air supply.

Fig. 9 Compressed air connection



Note!

If the pad is not in the starting position when the printer is switched on an error message will appear on the display.

Press the continue button on the printer to cancel the error state. The applicator will move into the start position and is ready for work.



Note!

Only mount the air pressure regulation unit as illustrated otherwise the functionality of the air-water separator cannot be guaranteed.

3.8 Test motion sequence and sensors




Note!

If the pad is not in the starting position when the printer is switched on an error message will appear on the display.

Press the continue button on the printer to cancel the error state. The applicator will move into the start position and is ready for work.

Der Applicator is ready for use.

No error message may be displayed in the basic position and the LEDs on all sensors light up except for the sensor end position of the lifting cylinder of the stamp assembly (Marker No.: 4).

By repeatedly pressing the button , the motion sequence of the applicator is run through.

3.9 Mounting the Suction Pads





Fig. 10 Mounting the suction pads

1. Loosen screws (3).
2. Use the adjusting tool (6) included (cab serial No.: 5972857) as shown in the picture to adjust the suction plates.
3. Slide each suction plate (4) over the corresponding driving pin (2) to the adjusting tool (6).
Mount the suction plates (4) so that the L connectors (hose connections) are accessible from the front.
4. Tighten screws (3).
5. Remove adjustment tool (6) downwards.
The lower surfaces must now be aligned at an angle of 0 ° and at a height to each other.
6. By repeatedly pressing the button , the motion sequence of the applicator is run through.
Then check the alignment of the tamps and adjust if necessary.

3.10 Mounting the Blow Tube




Fig. 11 Mounting the blow tube

The blow tube (3) can be rotated around its axis. By this principle the direction of the compressed air can be optimized.

1. Loosen the screw (1).
2. Insert the blow tube (3) as far as possible into the provided slot B (2).
3. Tighten the screw (1) to ensure the blow tube stays in place.
▷ „3.15 Adjustments to the Blow Tube (Supporting Air)“.



Attention!

All pneumatic settings have been made and optimized in the factory. Settings are only when changing corresponding components. according to the commissioning test report included in the scope of delivery. Settings must then be made by using the test report. The test report is part of the scope of delivery.

▷ Service Manual

Changes can be made to the setting of the strength of the supporting air and the vacuum in order to adapt it to the label material used.

3.11 Preparing the Tamp Assembly for Adjustments




Fig. 12 Preparing the tamp assembly for adjustments

1. Pull off the tube (1) from the L-connector (2) on the horizontal cylinder.
2. Align the suction pads (3) to the dispense edge of the printer ▷ „3.12 Adjusting the Pad“.
3. Connect the tube (1) to the L-connector (2).

3.12 Adjusting the Pad

For the perfect application of labels it is necessary that the pad is placed precisely above the dispensed label.

Aligning the pad parallel to the dispensing plate

The edge of the pad should be positioned parallel to the dispensing plate of the printer in order to position the label exactly on the pad.





Fig. 13 Aligning the pad to the dispensing plate

1. Loosen the knurled screw (3) and the set screw (4).
2. Screw in the knurled screw (3) until the stamp edges (5) are aligned parallel to the dispensing edge (6) of the printer.
3. Tighten the set screw (4) until it touches the printer.

Aligning the pad at an angle to the dispensing plate



4. If the angle between the tamp surface and the dispensing edge - support surface is not 0 ° loosen screw (2).
5. Correct the angle of attack by turning the eccentric (1).
6. Tighten screw (2).

3.12.1 Moving the Pad in Y-Direction




Fig. 14 Displacement in the Y direction

Displacement in the Y direction (printing direction)

1. Switch off the compressed air and pull the tube out of the throttle valve (5). The cylinder extends by spring force and is in the label transfer position.
2. Loosen screws (1) on the cross beam (2).
3. Move cylinder assembly (4) with the pad and crossbeam (2) along the guiding rail (3) that the distance from the edge of the pad (7) to the edge of the dispensing plate (8) of the printer is approximately 1 mm.
Orientation: Graduation (6)
4. Tighten screws (1).
5. Put the tube back into the throttle valve (5) and switch on the compressed air.

3.12.2 Moving the Pad in Z-Direction




Fig. 15 Displacement in the Z direction

Displacement in the Z direction (Height)

1. Switch off the compressed air and pull the tube out of the throttle valve (4). The cylinder extends by spring force and is in the label transfer position.
1. Loosen screw (3) on the binder (2).
2. Turn the setting screw (1) so that the bottom side of the pad is 1 mm over the top of the dispensing plate (6) of the printer.
3. Tighten screw (3).
4. Put the tube back into the throttle valve (4) and switch on the compressed air.

3.12.3 Moving the Pad in X-Direction




Fig. 16 Displacement in the Y direction

Displacement in the X direction (Side)

1. Loosen screw (3) on the binder (5).
2. Move cylinder assembly with the pad along the crossbeam (4) so that the dispensed label (7) is aligned centrally to the pad (6). As reference use the provided graduation/ruler on the crossbeam. Orientation: Graduation (2) and Marking (1)
3. Tighten screw (3).




Fig. 17 Label parameter

A misalignment of the stamp to the printer can be recognized by the increase in the length offset P and / or the bevel V (side offset)

- With bevel V (side offset) the parallelism of the stamp to the dispensing edge of the printer must be set.
- With length offset P, the position of the punch in the X direction must be set.

3.13 Setting the Peel Position

To optimize the transfer of the labels from the printer to the pad there are two different parameters available for adjusting the peel position.







Attention!


- ▶ First adjust the parameter "Peel Position" in the printer configuration.
- ▶ Then adjust the additional peel-off offset in the software.

It is very important to follow that procedure for a certain start after label loading and for the re-start after error treatment.

Parameter "Peel Position" in the printer configuration

- ▶ Check the basic settings in the printer setup. Perform labelling cycles by alternately pressing the  button and Enter button . ▷ „4.1 Test Mode without a Print Job“
- ▶ In the submenu  *Labelling* >  *Peel-off position* adjust the "Peel-off position" in such a way, that the blank labels are peeled-off completely from the liner
▷ „3.6 Configuration on the Printer“

Peel-off offset in the software

- ▶ Check the setting in the software. Perform labelling cycles by repeatedly pressing the button .
- ▶ Adjust the peel-off offset in such a way, that the printed labels are peeled-off completely from the liner
▷ Programming manual or software documentation.

3.14 Activation of Peel-off Mode



Note!

- ▶ For labelling operation activate the peel-off mode in the software.
- ▶ For direct programming use the P command ▷ Programming manual.

3.15 Adjustments to the Blow Tube (Supporting Air)

For optimal support during the acquisition of the label of the applicator the supporting air is to be set up so that it is free of turbulence and evenly pushes the label against the pad.

The default air pressure value is set to 2 bar.



Note!

When changing the used printer type (2", 4" or 6") the respective blow tube is to be used. With the correct blow tube the quantity of blow holes used and the air pressure and blow tube alignment should be adjusted respectively.




Fig. 18 Adjustment to the blow tube

The blow tube (3) for the relative air pressure can be turned on its own axis to optimize the support for the label acquisition.

1. Loosen screw (1).
2. Insert the blow tube (1) into the blow tube-slot B (2).
Turn the blow tube so that the airflow supports the label from the dispensing plate (5) to the pad (4).
 - For smaller labels turn the holes of the blow tube into the direction of the dispensing plate (4).
 - For larger labels guide a stronger airflow away from the dispensing plate (5) toward the pad (4).
Better orientation can be obtained by using the indicator at the base of the blow tube.
3. Tighten screw (1).




Fig. 19 Throttle valve for supporting air

The force of the compressed air can be varied via the throttle valve (1) to improve the blowing onto the label.

- To strengthen the supporting air turn the throttle valve (1) counter-clockwise.

3.16 Adjusting the Vacuum

Via the negative pressure the label is fixed to the applicator. This vacuum needs to be strong enough to hold the label and cover all suction apertures. It may not be strong enough to hinder the transport of the from the printer to the applicator. This is dependent on the label material used.

The default value of the vacuum is -0.6 bar.



Note!

By adjusting the vacuum it is possible to prevent the label from being applied to the product. If the vacuum is too strong the label will not be released by the pad.

If the vacuum is set too high the advancement of the label can be stopped before it reached the pad properly.




Fig. 20 Vacuum throttle valve

- Use the throttle valve (1) to ensure that the label is sucked up correctly over its entire surface.
- To strengthen the vacuum turn the throttle valve setting screw counter-clockwise.

3.17 Alignment of the Product to the Applicator

Depending on the orientation of the applicator to the printer the alignment of the product will take place



Note!

For optimal alignment of the product for labeling a fixed uptake of the product is necessary.




Fig. 21 Alignment of the product to the tamp

The product (3, 5) must be aligned 90° to the edge of the pad (1). Because the pad with the tongs (2) are parallel to the dispensing plate of the printer it can be used for the alignment.




Fig. 22 Examples of simple product uptake

With flexible products (5) both edges must be fixed to prevent the product from moving during the application process.

3.18 Setting the Application Height

- ▶ Dismount the cover ▷ „3.4 Mounting and Demounting the Cover“
- ▶ Place the product in the product-holder
- ▶ Switch off the compressed air.
- ▶ Pull the tubes out of the main cylinder Z-direction to be able to move the pliers manually.
- ▶ Move the pliers to the product manually.
- ▶ The upper edge (2) of the tamp assembly should be located directly under the lower edge of the workpiece (1). Design the appropriate bracket.
- ▶ The center of the workpiece (1) must be perpendicular to the closing plane of the two tamps (2).
- ▶ Loosen the screws (8) at the stopper (4) and screws (9) at the transport lock (3). Pull the Stopper (5) and the transport lock (3) all the way down to the slide until the shock absorber is fully pushed in.
- ▶ Tighten screw (8) at the stopper (4) and screw (9) at the transport lock (3).
- ▶ Fine adjustment by turning the shock absorber (6).

**Attention!**

The transport lock and stop must not hit the carriage (7) directly.

The carriage (7) may only touch the shock absorber (6).

- ▶ Put the tube back into the main cylinder Z-direction.
- ▶ Switch on the compressed air.
- ▶ Mount the cover ▷ „3.4 Mounting and Demounting the Cover“

**Attention!**

The stroke of the main cylinder is braked by the stop with the shock absorber (5), not by the workpiece!




Fig. 23 Adjust the application height

4.1 Test Mode without a Print Job








Fig. 24 Display

By alternating between buttons  and  on the display it is possible to simulate the labeling process without an active printing job.

- ▶ Push button .
This causes the feed of an empty label. Simultaneously the vacuum of the pad as well as the supporting air are activated. As soon as the label has securely arrived at the pad the supporting air is switched off.
- ▶ Push button .
When pushing this button the cylinder Z is extended into the labeling position. Reaching the labeling position is signaled by the triggering of the impact sensor. With that signal the vacuum is stopped and the label is applied to the product. With the application of the label the cylinder is contracted back into the starting position.



Note!

- ▶ Use the printer configuration to find the best peel-off offset for the initiation.

4.2 Test Mode with a Print Job

This method allows testing of the labeling process with actual printing data by using the  button.

- ▶ Send a print job.

The test mode is executed in two half cycles:

- ▶ Push the  button.


Half cycle 1

A label is printed. The vacuum of the pad as well as the supporting air (blow tube) are switched on. When the label has been picked up by the pad, the supporting air is switched off.

- ▶ Push the  button.

Half cycle 2

The pad is moved to the labelling position. The triggered impact sensor signals when the labelling position is reached. The vacuum is switched off as soon as the label is placed onto the product. Then, the pad is moved back into the starting position.

If the label is removed by hand after **half cycle 1** has been completed and the  button is pressed, **half cycle 1** will be repeated with the next label in the printing line.



Note!

- ▶ Use the software to find the best peel-off offset for the initiation.

4.3 Standard Operation

- ▶ Check all external connections.
- ▶ Load the material. Ensure that the locking system is locked ▷ "Operator's Manual" of the printer.
- ▶ Open the shutoff valve.



Attention!

- ▶ Ensure that the pad is not covered by a label when switching on the printer-applicator system. Otherwise the vacuum sensor may be calibrated incorrectly.

- ▶ Switch on the printer.



Note!

If the pad is outside the starting position when the printer-applicator system is switched on the procedure will be interrupted with an error message visible on the display.

Pushing the pause button on the printer will negate the error moving the pad to the starting position. The Applicator is ready for work.

- ▶ Press the  at the printer.

A synchronization feed is initiated. The processed labels have to be removed manually. After a few seconds the printer carries out a short backfeed to position the front edge of the next label at the printing line.



Note!

This synchronization also has to be carried out when the print job has been interrupted with the cancel key. Synchronizing is not necessary when the print head was not lifted between print jobs. This also applies if the printer was powered down between print jobs.

- ▶ Start a print job.
- ▶ Start the labelling process via PLC interface.


Error messages during labelling process are shown in the display of the printer ▷ 4 Error Messages.

4.4 Cleaning



Attention!

- ▶ Never use solvent or abrasive.



- ▶ Clean the outside surfaces with multi purpose cleaner.
- ▶ Remove dust particles and leftover label pieces with a soft brush and/or vacuum cleaner.
- ▶ The label contact surface (1) requires regular cleaning as the most dirt is deposited here.


Fig. 25 Cleaning of the pad with slide foil

5.1 Error Messages of the Printer

For detailed information about printer errors (e.g. 'Paper out', 'Ribbon out', etc.) ▷ Check the operator's manual of the printer.

Error treatment:

- Clearing the error results.

- Press the  to synchronize the label feed, remove the left over labels manually.

To quit the error state press *Repeat*.

After error correction, the label causing the error will be reprinted.

5.2 Error messages of the applicator

The following table contains an overview of error messages and their possible causes. It also suggests methods to resolve the problem :

Error Message	Possible Cause
<i>Air pressure error</i>	Compressed air is switched off
	Pressure to low < 4 bar
	Pressure to high > 6 bar
<i>Label not depos.</i>	Label has not been placed onto the product; after the pad has moved back the label still sticks on the pad
<i>Upper position not reached</i>	Pad is not in start position if the printer switched on
	Pad has not reached the home position within 2s after the movement of the pad was started
	Pad has undefined leaving the start position
<i>External error</i>	Process of labeling was braked via the I/O interface of the printer with the XSTP signal
<i>Upper position not left</i>	There has been no change of the switch state at the upper sensor at the cylinder between the start of the labelling process and the signal from the labelling position sensor
<i>Vac. plate empty</i>	Label has not been picked up properly by the pad; or label fell off the pad before it could be placed onto the product
<i>Lower position not reached</i>	Pad has not reached the starting position within 2s after the pad has left the labelling position; or pad has left the starting position unauthorized

Table 3 Error messages of the applicator

Error treatment:

- Clear the error state.
- In order to clear the error state press **continue**, **repeat** or **cancel**.
 - Continue* with the next label in the printing queue.
 - Repeat* respectively the **pause** and enter ↵ key repeat the print of the label causing the error. Only applicable with error *Vac. plate empty*.
 - Cancel* the current print job.




Warning!

After the error has been resolved the pad will immediately move back to the starting position!

Danger of injury to hands and fingers by the moving pad!

- **Do not reach into the area of the moving pad and keep long hair, loose clothes, and jewelry away.**

Reprinting a label, interrupted by an error, is not possible without a new printing job.

- In the mode "apply/print" before the standard cyclic operation can commence the signal "print first label" must be sent or push  respectively the enter ↵ key to send a printed label to the pad.

6.1 Declaration of Incorporation




cab Produkttechnik
GmbH & Co KG
Wilhelm-Schickard-Str. 14
D-76131 Karlsruhe
Germany

Declaration of Incorporation

We declare herewith that the following „partly completed machinery“ as a result of design, construction and the version put in circulation complies with the essential requirements of the **Directive 2006/42/EC on machinery**:

Annex I, Article 1.1.2, 1.1.3, 1.1.5, 1.1.6, 1.2.1, 1.3.2, 1.5.2, 1.5.8, 1.6.3, 1.7

In the event of any alteration which has not been approved by us being made to any device as designated below, this statement shall thereby be made invalid.

Device:	Flag Applicator
Type:	4712
Applied EU Regulations:	Applied Standards
Directive 2006/42/EC on machinery:	<ul style="list-style-type: none"> • EN ISO 12100:2010 • EN ISO 13849-1:2015 • EN 60950-1:2006 +A11:2009+A12:2011+A1:2010+A2:2013
Person authorised to compile the technical file:	Erwin Fascher Am Unterwege 18/20 99610 Sömmerda
Signed for, and on behalf of the Manufacturer:	Sömmerda, 08.07.2019  Erwin Fascher Managing Director
cab Produkttechnik Sömmerda Gesellschaft für Computer- und Automationsbausteine mbH 99610 Sömmerda	

The product must not be put into service until the final machinery into which it is to be incorporated has been declared in conformity with the provisions of the Directive on machinery.

The documents according annex VII part B from the incomplete machinery are created and will commit to state agencies on request in electronic kinds.


6.2 EU Declaration of Conformity



cab Produkttechnik
GmbH & Co KG
Wilhelm-Schickard-Str. 14
D-76131 Karlsruhe
Germany

EU Declaration of Conformity

We declare herewith that as a result of the manner in which the device designated below was designed, the type of construction and the devices which, as a result have been brought on to the general market comply with the relevant fundamental regulations of the EU Rules for Safety and Health. In the event of any alteration which has not been approved by us being made to any device as designated below, this statement shall thereby be made invalid.

Device:	Flag Applicator
Type:	4712
Applied EU Regulations:	Applied Standards
Directive 2014/30/EU relating to electromagnetic compatibility:	<ul style="list-style-type: none"> • EN 55032:2012 • EN 55024:2010 • EN 61000-6-2:2005
Directive 2011/65/EU on the restriction of the use of certain hazardous substances in electrical and electronic equipment:	<ul style="list-style-type: none"> • EN 50581:2012
Commission delegated directive (EU) 2015/863 amending Annex II to Directive 2011/65/EU of the European Parliament and of the Council as regards the list of restricted substances	
Signed for, and on behalf of the Manufacturer:	Sömmerda, 08.07.2019
cab Produkttechnik Sömmerda Gesellschaft für Computer- und Automationsbausteine mbH 99610 Sömmerda	 Erwin Fascher Managing Director