

Assembly Transport safety 1 / Part No. 8913151

| Step | Description | Notes |
|------|---|--|
| 1. | Attach the front safety bar (picture 2) to the front side of the fixed rack wall. | <ul style="list-style-type: none"> - Push the washer to the flat head screw - Attach the upper long hole to the upper thread on the left profile (1) <ul style="list-style-type: none"> - Push the washer to the flat head screw - Attach the lower long hole to the lower thread on the left profile (2) |
| 2. | Attach the back safety bar (picture 3) to the back side of the fixed rack wall. | <ul style="list-style-type: none"> - Push the washer to the flat head screw - Attach the upper long hole to the upper thread on the left profile (3) <ul style="list-style-type: none"> - Push the washer to the flat head screw - Attach the lower long hole to the lower thread on the left profile (4) |

© Copyright bei cab/9009024/Status 12/2014

Attention: not for reversible use!

