

Ersatzteile Leiterplattenmagazine 707

Ausgabe 03/2014



Pos.	Benennung	Artikel-Nr.		
		Typ 707 (alt) 8913077	Typ 707.2 8916707	Typ 707.3 8915707
1	Stegwand fest, kpl	8915433.001	8915406.001	8914999.001
2	Stegwand verstellbar, kpl.	8915434.001	8915407.001	8915007.001
3	Profil	8913066.001	8913065.001	8913065.001
4	Standardriegel	8913119.001	8913119.001	8913119.001
5	Wenderiegel	8913014.001	8913014.001	8913014.001
6	Transportsicherung 2	8913152.001	8913152.001	8913152.001
7	Transportsicherung 1	8913151.001	8913151.001	8913151.001
8	Spannrolle, kpl.	8913179.001	8913179.001	8913179.001
9	Positionierstreifen	8913115.001	8913115.001	8913115.001
10	Deckplatte, kpl.	8913185.001	8915442.001	8915248.001
	Deckplatte, vormont. (Ersatzteil)	8913231.001	—	—
11	Spindel	8913105.001	8913105.001	8913105.001
12	Klemmring	8913220.001	8913220.001	8913220.001
13	Riemenrad	8913019.001	8913019.001	8913019.001
14	Lagerwinkel, kpl.	8913013.001	8913013.001	8915286.001
15	Mutter	8913015.001	8913015.001	8913015.001
16	Lagerbock	8913009.001	8913009.001	8913009.001
17	Grundplatte, kpl.	8913184.001	8913184.001	8915247.001
	Grundplatte, vormont. (Ersatzteil)	8913232.001	—	—
18	Platte oben	8913129.001	8913129.001	8913129.001
19	Platte	8913025.001	8913025.001	8913025.001
20	Klemmplatte	8913107.001	8913107.001	8913107.001
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31	Schraube DIN7985-M 4x10-4.8	5902022.001	5902022.001	5902022.001
32	Schraube DIN7985-M 3x8	5902069.001	5902069.001	5902069.001
33	Schraube DIN7985-M3x10	5902061.001	5902061.001	5902061.001
34	Schraube DIN923-M3x 2	5902339.001	5902339.001	5902339.001
35	Schraube DIN7985-M 5x16	5902350.001	5902350.001	5902350.001
36	Schraube M4x12 rot	5902351.001	5902351.001	5902351.001
37				
38	Mutter DIN934-M 3-8	5902505.001	5902505.001	5902505.001
39	Scheibe DIN9021-4,3	5903005.001	5903005.001	5903005.001
40	Passscheibe DIN988- 6x12x0,3	5903008.001	5903008.001	5903008.001
	Passscheibe DIN988- 6x12x0,2	—	5903025.001	5903025.001
41	Zahnscheibe DIN6797 A4.3	5903011.001	5903011.001	5903011.001
42	Passscheibe DIN988- 4x8x1,0	5903089.001	5903089.001	5903089.001
43	Sicherungsscheibe DIN6799-5	5903505.001	5903505.001	5903505.001
44	Zahnriemen 828XL 025	5905558.001	5905558.001	5905558.001
45	Schlüssel DIN911-2,5mm	5909031.001	5909031.001	5909031.001
46	Montageanleitung	9008261.001	9008261.001	9008261.001
47				
48				
49				
50				
51				
52				
53				
54				
55				

Ersatzteile Leiterplattenmagazine 717

Ausgabe 03/2014



Pos.	Benennung	Artikel-Nr.		
		Typ 717 (alt) 8913547	Typ 717.2 8916717	Typ 717.3 8915717
1	Stegwand fest, kpl	8915406.001	8915406.001	8914999.001
2	Stegwand verstellbar, kpl.	8915407.001	8915407.001	8915007.001
3	Profil	8913066.001	8913065.001	8913065.001
4	Standardriegel	8913119.001	8913119.001	8913119.001
5	Wenderiegel	8913014.001	8913014.001	8913014.001
6	Transportsicherung 2	8913152.001	8913152.001	8913152.001
7	Transportsicherung 1	8913151.001	8913151.001	8913151.001
8	Spannrolle, kpl.	8913179.001	8913179.001	8913179.001
9	Positionierstreifen	8913115.001	8913115.001	8913115.001
10	Deckplatte, kpl.	8913185.001	8913185.001	8915378.001
	Deckplatte, vormont. (Ersatzteil)	8913231.001	—	—
11	Spindel	8913105.001	8913105.001	8913105.001
12	Klemmring	8913220.001	8913220.001	8913220.001
13	Riemenrad	8913019.001	8913019.001	8913019.001
14	Lagerwinkel, kpl.	8913013.001	8913013.001	8915286.001
15	Mutter	8913015.001	8913015.001	8913015.001
16	Lagerbock	8913009.001	8913009.001	8913009.001
17	Grundplatte, kpl.	8913184.001	8913184.001	8915247.001
	Grundplatte, vormont. (Ersatzteil)	8913232.001	—	—
18	Platte oben	8913129.001	8913129.001	8913129.001
19	Platte	8913025.001	8913025.001	8913025.001
20	Klemmplatte	8913107.001	8913107.001	8913107.001
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31	Schraube DIN7985-M 4x10-4.8	5902022.001	5902022.001	5902022.001
32	Schraube DIN7985-M 3x8	5902069.001	5902069.001	5902069.001
33	Schraube DIN7985-M3x10	5902061.001	5902061.001	5902061.001
34	Schraube DIN923-M3x 2	5902339.001	5902339.001	5902339.001
35	Schraube DIN7985-M 5x16	5902350.001	5902350.001	5902350.001
36	Schraube M4x12 rot	5902351.001	5902351.001	5902351.001
37				
38	Mutter DIN934-M 3-8	5902505.001	5902505.001	5902505.001
39	Scheibe DIN9021-4,3	5903005.001	5903005.001	5903005.001
40	Passscheibe DIN988- 6x12x0,3	5903008.001	5903008.001	5903008.001
	Passscheibe DIN988- 6x12x0,2	—	5903025.001	5903025.001
41	Zahnscheibe DIN6797 A4.3	5903011.001	5903011.001	5903011.001
42	Passscheibe DIN988- 4x8x1,0	5903089.001	5903089.001	5903089.001
43	Sicherungsscheibe DIN6799-5	5903505.001	5903505.001	5903505.001
44	Zahnriemen 828XL 025	5905558.001	5905558.001	5905558.001
45	Schlüssel DIN911-2,5mm	5909031.001	5909031.001	5909031.001
46	Montageanleitung	9008261.001	9008261.001	9008261.001
47				
48				
49				
50				
51				
52				
53				
54				
55				

PCB-Magazine Series: 701 - 703 (alt), 704 (alt), 801 - 809 (alt)


Series: 701.1 - 704.1


Series: 701.2 - 703.2

Series: 704.2 - 719.2

Series: 801.1 - 804.1

Series: 804.2 - 809.2





PCB-Magazine Series: 701-703 (Ausführung alt: Blech)

Series: 704 (alt)

Series: 704.1 / 704.2 / 704.3

Series: 705 (alt) 719 (alt)

Series: 705.2 bis 719.2

Series: 705.3 719.3

