

Assembly Transport safety 2 / Part No. 8913152

Step	Description	Notes
1.	Attach the front safety bar (picture 2/dim. 90,15 mm) to the front side of the fixed rack wall.	<ul style="list-style-type: none"> - Push the washer to the flat head screw - Attach the upper long hole to the upper thread on the left profile (1) - Push the washer to the flat head screw - Attach the lower long hole to the lower thread on the left profile (2)
2.	Attach the back safety bar (picture 3/dim. 74,15 mm) to the back side of the fixed rack wall.	<ul style="list-style-type: none"> - Push the washer to the flat head screw - Attach the upper long hole to the upper thread on the left profile (3) - Push the washer to the flat head screw - Attach the lower long hole to the lower thread on the left profil (4)

© Copyright bei cab/9008262/Status 12/2014

